



motoalliance

**VIPER PLOW SYSTEM / Can Am/Bombardier Outlander
2008-09 400/500/650/800 MA11142**

Thank you for purchasing the premium VIPER PLOW system. You now have a top-of-the-line plow system to using for shoving aside snow and dirt with the use of your ATV. Please note the following instructions and heed all warnings.

WARNING!!!

SEVERE INJURY OR DEATH MAY RESULT IF YOU IGNORE ANY OF THE FOLLOWING.

- Read the Plow Operator's Manual, the Winch Operator's Manual, and all warning labels before operating.
 - Operate ATV at a walking speed with the blade installed. Do Not exceed 5mph (8 km/h) even with the blade up.
 - Plow Cautiously, impact with a hidden or stationary object may cause the ATV to stop suddenly or go out of control.
 - Do Not operate the ATV on slopes greater than 10° with the plow installed.
 - Do Not stand or ride on the plow.
- Stay clear of moving parts and joints. Keep others away when operating or adjusting plow.
- Inspect the plow mechanism, fasteners, cable, and adjustments before operating. Replace all worn or damaged parts before operating.
 - Lower the plow to the down position before leaving the ATV unattended.



PARTS LIST

- 1 Plow Mount
- 1 Plow Mount Strap
- 4 5/16-18 X 1 1/2 Hex Bolt
- 4 5/16 Flat Washer
- 4 5/16-18 Lock Nut
- 3 3/8-16 X 1 Hex Bolt
- 3 3/8 Flat Washers
- 3 3/8-16 Nylock Nuts

CAUTION

USE EXTREME CAUTION WHEN DRILLING THROUGH THE SKIDPLATE. EVERY EFFORT HAS BEEN MADE TO ENSURE THAT THE HOLE POSITIONS ON THE CROSSMEMBER WILL NOT ALLOW THE DRILL BIT TO CONTACT ANYTHING ELSE ON THE BIKE. BUT VARIATIONS IN MANUFACTURING AND INSTALLATION MAY CHANGE THAT. KEEP AWAY ALL HANDS AND LIMBS THAT MAY BE IN THE PATH OF THE ROTATING BIT. ONLY DRILL THROUGH THE SKIDPLATE AND NOTHING ELSE ON THE BIKE. NOT DOING SO MAY SERIOUSLY DAMAGE/INJURE THE BIKE AND OPERATOR.

CAUTION

FAILURE TO TIGHTEN THE MOUNTING BRACKET BOLTS MAY CAUSE SERIOUS DAMAGE TO YOUR PLOW MOUNT AND BIKE. BE SURE TO TIGHTEN THEM SNUGLY.

Plow Mount Assembly:

1. Remove the four bolts as shown in figure 1.



Figure 1 - Remove Bolts

2. Place the plow mounting base plate into location as shown in figure 2. Secure with four 5/16-18 X 1 1/2 hex bolts, 5/16 flat washers and 5/16-18 lock nuts all supplied in the plow mounting kit.

Note: Do not tighten at this time.



Figure 2 - Install Plow Mount

3. Place the plow mounting strap into location as shown in figure 3. Secure with two 3/8-16 X 1 hex bolts, 3/8 flat washers and 3/8-16 lock nuts.
Tighten all hardware at this time.




Figure 3 - Plow Mount Strap Location

Plow Installation:

1. Slide the plow into position with the tubes under the ATV. Lift the end of the tube assembly into position so the holes in the tube wings line up with the 3/8" holes in the frame brackets (Figure 2).
2. A Phillips head screwdriver may be used to align the holes. Insert both 3/8" pins and hook the retaining clips on the ends of the pins to secure the plow to the ATV.
3. The plate should now be a permanent part of your ATV and will not interfere with clearance. The plow can be easily attached and detached on the welded u-bolt with the clevis hook on a winch or a manual lift assembly.

Plow mount installation is now complete.

