



## TECHNICAL TIP T7-17-0001

Instructions for 102 & 153 stud patterns on a 146"/371cm single-ply track with 2.86 pitch using the 129S Template

Use these instructions to create:

102 stud pattern on a 146"/371 cm tracks.

153 stud pattern on a 146"/371 cm tracks.

Refer to the picture on Woody's 129S-TEMP template. Note, the 90 and 135 stud patterns have a specific sequence of letters.

Note: **A PITCH is the space between each lug row.**

This 129S-TEMP template will accommodate 15" & 16" / 38cm & 41cm wide tracks. At the ends of each lug slot a portion of the template is outlined in a black dotted line.

- To fit a 15"/38cm wide track leave the dotted outlined area intact. If the black dotted outlined area has been removed, the modified template should not be used on 15" wide track widths.
- To fit a 16"/41cm wide track remove the area inside the dotted lines.

### 102 Pattern

Use the 90 single, center belt pattern on the 129S-TEMP.  
Repeat this pattern 8.5 times.



### 153 Pattern

Use the 135 single/double, center belt pattern on the 129S-TEMP.  
Repeat this pattern 8.5 times.



**WARNING** Review the snowmobile and track manufacturer's studding recommendations in your owner's manual. You may void your warranty if their recommendations are not followed. You must read and understand these instructions before drilling holes in your track, if you have any questions contact Woody's through the methods listed below.