

# ATV-TEK

## ARCH SERIES – OVERSIZED CARGO BAG

### Assembly Instructions

PARTS IDENTIFIER:




Front Compartment (2)



Front Bag Side wall (2)



Tensioning Rod (4)



Side Rail (2)



Side Bags (2)



Mesh Side Bag (2)



Top Seat Pad (1)



Seat Bottom (1)



Foam Separator (1)



Water Bottle Holder (1)




Cargo Bag Lid (1)



Cargo Bag Skin (1)

## STEP 1: Insert Side Rails

- Insert each side rail into the cargo bag skin. Attach the Velcro at the bottom of each corner.



## STEP 2: Insert Bottom Tensioning Rods

- Wedge each of the tensioning rods between the two side rails. Push until the rod snaps into place and slide it toward the outside of the bag until it rests against the Velcro strap.



## STEP 3: Attach Inner Side Bags

- Attach the Velcro for each of the four side bags on the side rails. Be sure to attach them between the three Velcro straps on the outer skin.



## STEP 4: Attach Top Velcro Straps

- Attach the top three Velcro straps on each side rail. Pull down firmly on strap to tighten the cargo bag skin.



## STEP 5: Insert Top Tensioning Rod

- Wedge the top tensioning rod until it snaps onto the side rail. Slide the rod until it rests at the edge of the bag.



## STEP 8: Fold Front Flap

- Fold the front flap inwards on each of the front compartments and attach Velcro.



## STEP 6: Attach the Side Velcro Straps

- Pull each of the straps over the tensioning rod on each side of the bag.



## STEP 9: Insert Side Wall

- Press the side walls into the front compartments. Do not attach the Velcro at this point.




## STEP 7: Insert Foam Separator

- Attach foam separator to Velcro in any one of the three velcro strips.



## STEP 10: Fold Flap Under Sleeve

- Bend the side wall until a corner will insert under the side sleeve. Press it flat into the top of the sleeve.



## STEP 11: Attach Water Bottle Holders

- Attach the Velcro on the side of the front compartment to the water bottle holder.



## STEP 12: Attach Seat

- Loop the seat bottom and Attach the Velcro. Attach the Velcro on the seat top to the seat bottom. Attach the Velcro loops on the seat top.



## STEP 13: Attach Side Compartments

- Loop the front Velcro straps on the side compartment to attach it to the main Cargo bag. Attach the rear straps likewise.



ATV Tek puts everything within reach.



## STEP 14: Attach Cargo Bag Lid

- Buckle all eight buckles to attach the lid to the Cargo Bag.



## STEP 15: Attach to ATV

- Loop the tie down strap around the ATV rack and send to loop through the middle hole on the buckle. Loop the strap back down through the bottom hole and pull the strap securely onto the ATV.



Find out more about luggage systems & organizers we have.