



***baja designs***<sup>®</sup>  
The Scientists of Lighting

**Can-Am, Maverick X3 OnX6 Shock Mount Kit**

**44-7089**





**baja designs**  
The Scientists of Lighting

#### Exclusions:

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

#### Instructions for Can-Am, Maverick X3 S8 Shock Mount Kit.

1. Remove Hood. The hood is held in by 5 rubber grommets. Begin by gently pulling up on the rear of the hood. Work your way towards the front to fully remove the hood.



2. Next, remove the two 10mm bolts at the front of the shock mount holding the radiator support on. This will require a 10mm socket and a 10mm wrench behind the shock tower.
3. Place the Shock mount with the horns facing forward and push the two existing 10 mm bolts through the two holes with the provided washers. Place the two





**baja designs**  
The Scientists of Lighting

nylon locknuts on the back of the bolts and tighten until snug. Be sure to center your bracket with the shock mount.

4. Re-attach the hood by pressing firmly over each grommet location, begin at the front of the vehicle.
5. Attach the light by with the four 1/4"-20 bolts on each side of the light (if installed) There should be two 1/4"-20x 5/8" bolts go towards the front of the light, while the 1/4"-20x 1.25" will be towards the back



6. Adjust the light to the desired angle and snug bolts down.

(See wiring harness instructions for your electrical instructions.)

Rely only on high-grade off-road lights offered on our virtual shelves.