



# DENALI Plow Mount

## MA11701

### Polaris Ranger MidSize

Thank you for purchasing a DENALI plow mount. You now own a premium, custom plow mount to allow you to use your plow with your UTV/SxS. Please note the following instructions and heed all warnings.

- Your UTV/SxS and/or plow system can cause death or injury. Please use caution and common sense when operating your unit.
- Read your Plow Operator Manual, your Winch Operator Manual, and all warning labels before operating your UTV/SxS.
- Operate your UTV/SxS at a walking speed with the blade installed. Do not exceed 5 mph (8 km/h) even with the blade up.
- Do not operate the UTV/SxS on slopes greater than 10 degrees with the plow installed.
- Always lower the plow to the down position before leaving your UTV/SxS unattended.

**SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.**

**MA11701**

**Polaris Ranger MidSize Plow Mount**

Please verify that all hardware and parts are included in your package.

**Kit Contents:**

Part #	Qty	Description
1	1	MA11701 Mount Plate
2	1	2 Hole Mount Strap
3	1	3 Hole Mount Strap
4	2	Single Hole Strap
5	2	1/2" x 1-1/4" Hex Bolts
6	2	1/2" Lock Washer
7	2	1/2" Flat Washer
8	5	3/8" x 1-1/4 Hex Head Bolt
9	5	3/8" Flat Washer
10	5	3/8" Nylock Nut

1. Use a 1/2" Socket to remove the front three (3) lower bumper bolts (circled red in Figure 1) and set them aside for future use.



**Figure 1**

**MA11701**

**Polaris Ranger MidSize Plow Mount**

---

2. Hold the MA11701 Mount Plate (part #1) up to the front brush guard of the Ranger as shown in Figure 2 and Figure 3 and secure with the 3 bolts removed in Step 1. Do not tighten down at this time.



**Figure 2**



**Figure 3**

3. **For Polaris Ranger Mid-Size 400/500/800:** Bolt up the rear portion of the MA11701 Mount Plate (part #1) by placing the 2 Hole Mount Strap (part #2) inside the frame and bolt up through the mount and into the strap with the two (2) 1/2" x 1-1/4" Hex Bolts (part #5), the two (2) 1/2" Lock Washers (part #6), and the two (2) 1/2" Flat Washers (part #7).
4. **For Polaris Ranger Mid-Size 570:** Bolt up the rear portion of the MA11701 Mount Plate (part #1) by placing the 3 hole mount strap inside the frame of the UTV. Just below the radiator there is a small opening with three holes that will align with the 3 Hole Mount Strap (part #3). Use three (3) 3/8" x 1-1/4" Hex Head Bolts (part #8), three (3) 3/8" Flat Washers (part #9), and three (3) 3/8" Nylock Nuts (part #10) to secure the mount.

## MA11701

### Polaris Ranger MidSize Plow Mount

---

5. Bolt the front outside portion of the MA11701 Mount Plate (part #1) to the bumper by putting the two (2) Single Hole Straps (part #4) inside the bumper as shown in Figure 2 and Figure 4 and securing it with two (2) 3/8 x 1-1/4 Hex Head Bolts (part #8), two (2) 3/8" Flat Washers (part #9), and two (2) 3/8" Nylock Nuts (part #10).



**Figure 4**

6. Verify that the mount is flush to the machine and tighten down all hardware evenly.
7. Attach the plow using the quick release pins included with DENALI Plow Kits.

## After First Time Use

After the first use of your plow, check and retighten all hardware at least once, in case your frame has flexed and the Plow Mount has loosened.