



Plow Mount Installation Instructions

Polaris Ranger 2002-2008 – MA11707

Hardware List

- | | | | |
|-----|------------------|-----|--------------------|
| (1) | Plow Mount Plate | (4) | 3/8 x 1 1/4" Bolts |
| (4) | 3/8" nylock nuts | (8) | 3/8" Flat Washers |
| (1) | Mount Strap | | |

Installation Instructions

Install front plow mount to the machine by first removing the three bolts under the machine, shown in illustration. Attach plow mount reusing the bolts you just removed, align for best fit and just snug bolts at this time.

The top of the mount will be held in place with four 3/8 x 1 1/4" bolts. Install the four 3/8 x 1 1/4" bolts and flat washers from the front through the mount and through the machine and use the formed strap on the inside. Use four flat washers and Nylock nuts to secure. Tighten all bolts.

Note: After use recheck bolt tension Use two quick release pins to attach plow to plow mount.

