



Plow Mount Installation Instructions

Kawasaki Teryx MA11733

Hardware List

(1)	Plow Mount Plate	(4)	3/8" Flat Washers	(2)	Quick Release Pins
(2)	3/8" Nylock Nuts	(4)	5/16" Flat Washers		
(2)	Straps	(4)	5/16 x 3 3/4" Hex Bolts		
(2)	3/8" x 1 1/4" Bolts	(4)	5/16 Lock Washers		

Installation Instructions

Attach plow mount to your machine per illustration. NOTE: The front will require some trimming of the plastic to fit securely in place. The front of the plow mount will bolt to the bottom side of the front frame plate using 2-3/8 x 1 1/4" bolts, washers and nylock nuts. The back will attach using the two straps going over the top of the frame and the 5/16 x 3-3/4" with flat washers and lock washers going up through the plow mount and along side the frame and into the small strap with nuts on it. Make sure mount is up tight to machine and tighten bolts.

