



**FEEL THE HEAT!**

## RZR XP 1000 H.D. Rear Receiver Hitch Instructions

Part # <b>16-1170</b>	H.D. Rear Receiver Hitch for RZR XP 1000, XP4 1000, XP Turbo & XP4 Turbo	Black
Part # <b>16-1171</b>	H.D. Rear Receiver Hitch for RZR XP 1000, XP4 1000, XP Turbo & XP4 Turbo	Red
Part # <b>16-1172</b>	H.D. Rear Receiver Hitch for RZR XP 1000, XP4 1000, XP Turbo & XP4 Turbo	Blue

Congratulations on your purchase of the DragonFire H.D. Rear Receiver Hitch for the XP 1000! Designed to fit all 2 and 4 seat RZR XP 1000 seat models, this product provides towing capabilities, tie off points and a strengthened linkage brace plate to the rear of your machine. Hand welded in the USA and built to be the best all-around receiver hitch solution for the RZR XP1K, this Heavy Duty product will not let you down in any situation!

*\*Designed for standard 2" hitch \**

### **WARNING**

- Do not use if there is any sign of damage to product
- Not intended for use with tongue weight exceeding 500 lbs.
- Hitch may decrease departure angle and ground clearance.

### **Disclaimer**

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

### **Tools Required**

Floor Jack & Stands

1/2" wrench

3/4" wrench

15mm socket & wrench

**Step 1:** Place vehicle on a flat and level surface. Place gear selector in park and remove keys from the ignition.

**Step 2:** Lift rear of vehicle and secure with jack stands.

**Step 3:** Unbolt factory plate brace on the rear links and remove. Retain factory nuts to be reused.

**Step 4:** Install the hitch using supplied hardware. The longer bolts will be used on the lower mounting holes and will need the spacer between the hitch and the rear suspension radius rods. (Figure A) Use the shorter bolts on the upper mounts.

**Note:** Spacers are not necessary if hitch is placed over the DragonFire RacePace rear bumper (sold separately). (Figure B)

**Step 5:** Torque bolts to factory specifications. Time to ride and enjoy!

**ProTip:** Periodically check all hardware and re-tighten if needed.

**For further assistance please contact your authorized DragonFire dealer**

