



PREMIUM MINI BOARD without ADAPTER

4393

PARTS INCLUDED

- 2 Premium Mini Board Assemblies without Adapters
- 1 Hardware Kit Containing:
 - 2 5/16" Flat Washers
 - 2 5/16"-18 X 1" Socket Head Cap Screws
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE

IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.

TOOLS SUGGESTED

Set of Hex Wrenches, Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
- STEP 2** Remove the stock peg from the peg mount. Pay attention to any spacers or washers installed between the peg mount and the clevis, it may be helpful later. Keep the mounting hardware, it may be reused.
- STEP 3** Install the new peg adapter as per the instructions with the peg adapter. Check that the peg adapter is installed correctly and the adapter is able to fold up.

-cont.-

STEP 4

There are three mounting holes with splines around them in the Mini Board. Use these to locate the Board forward or rearward, tilt up or down, from the stock peg location. Once you have decided on the location and orientation, insert the 5/16"-18 socket head cap screw, with flat washer, through the Board and thread it into the mount making sure the splines on the Board are engaged in the splines on the mount in the desired location. Tighten securely.

⚠ WARNING

ENSURE THAT THE INSTALLATION OF THESE MINI BOARDS DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BEFORE RIDING. INTERFERENCE WITH THE CONTROLS OR ANY COMPONENT ON THE MOTORCYCLE MAY CAUSE LOSS OF CONTROL RESULTING IN SERIOUS INJURY OR DEATH.

NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

*Ride On!***PAGE****2****PREMIUM MINI BOARDS****INSTALLATION**