

TOOLS YOU WILL NEED:

- Torx T-30 Sockett
 - Torx T-20 Sockett
 - Flathead Screwdriver
 - 3/4" Drill Bit
 - Drill
- *Having a full set of torx bits is a good idea for working on your UTV*

1. Remove the Center Console Cover.
2. Remove the Front Top Console.
3. Mount bracket with provided hardware.
4. Drill $\frac{3}{4}$ inch hole 1 $\frac{1}{2}$ Inches high on the Center Console Cover for wire routing.
5. Hand tighten intercom into bracket
6. Install the Front Top Console and bracket into car.
7. Install radio from the driver's side into the bracket and tighten down with provided hardware.
8. Tighten the 4 bolts on the front of the intercom. (Make sure to tighten the radio first)
9. Re Install the Center Console Cover and run wiring through the hole.

