

POLARIS RZR XP PRO

RADIO/INTERCOM INSTALLATION INSTRUCTIONS



PROVIDED HARDWARE:

- (6) 8-32 x 3/8" screws
- (2) hole plugs
- (4) push rivet

TOOLS YOU WILL NEED:

- T-40 Torchmate
- 10mm socket
- Pliers
- 4mm Allen
- Box cutter, saw, or cutoff

1. Unclip and Remove Seats.
2. To remove the Center Console, remove the Torx bolts, two twist lock bolts and the push rivets along the perimeter of the console.
3. Remove the bolt under the rubber flap to the rear of the shift lever bezel near the cup holder.
4. Remove the bolts at the top and the bottom of the fuse box located under the dash on the driver side of the console. Push the fuse box to the side to remove the center console.
5. Remove the push pins that hold the dash to the center console and disconnect cigar power plug.
6. After all hardware is removed, pull the center console top bezel out of the vehicle so it can be cut. From the front of the mounting tab to the center of the console, measure 1 3/4" back from both sides. Cut straight across the width of the console at these markings. (The bracket will cover the cut marks) See the two photos for step 6. Check out our YouTube channel for a video showing where to cut the center console.
7. Where the shift lever bezel meets the center console, measure 3/4" forward. Cut straight across the width of the console.
8. Using the hardware removed in steps 2-4, reassemble the front half section of the console and fuse assembly to the original position.
9. Reassemble the rear console cut piece back to the original position using the stock hardware. The middle section can be discarded.
10. Relocate the Cigar Power plug to the new bracket. Push to talk buttons can be mounted in the bracket or use the plugs to fill the holes. Before installing the rest of the bracket, run the intercom power, radio power, intercom cables, push to talk buttons and coax cable down the center console. Keep headset/helmet cables, antenna cable and power cables as far apart from each other as possible, do not run in the same loom. Reference routing instructions included with intercom.
11. Install the radio and intercom into the bracket using hardware from the radio and intercom box. Assemble the angled side bracket to the radio/intercom bracket using the provided hardware.
12. Place the bracket in the farthest forward position and align against the switch panel and shift bezel.
13. Drill four 5/16" holes using the side panels as a guide.
14. Insert the provided push rivets to attach the bracket to the console.

