

# POWERMADD® Pro-Ride Windshields

## Installation Instructions for Part No. 11830 & 11840

### HARDWARE INCLUDED:

<u>Qty</u>	<u>Description</u>
1	Windshield
8	Well Nuts
8	Snap Cap Washers
8	Black Snap Caps
8	Screws

### TOOLS REQUIRED:

<u>Description</u>
Drill
3/8 Drill Bit
Phillips Screwdriver
Standard Screwdriver
Needle Nose Pliers

**STEP 1:** Start by removing the stock windshield. Use a needle nose pliers or standard screwdriver to remove the push pins holding the windshield on.

**STEP 2:** Once the windshield is removed insert six of the well nuts into the holes in the pod. **Note:** You might need to enlarge the holes with the 3/8 drill bit if the well nuts do not fit. *Photo 1*

**STEP 3:** Set the new windshield in place and install the six screws. You do not need to install the bezel/trim at this time. *Photo 2*



Photo 1

Continued on next page...



**STEP 4:** Once the windshield is secure, mark the location of the two rear mounting holes with the tip of your screwdriver. *Photo 3*

**STEP 5:** Remove the six screws and then the windshield.

**STEP 6:** Use the 3/8 drill bit to drill the holes in the location marked in step 4. **Note:** Use caution when drilling as to not drill too deep. *Photo 4*



Photo 3

**STEP 7:** Insert the last two well nuts into the holes you just drilled.

**STEP 8:** Set the windshield bezel into place.

**STEP 9:** Insert the eight screws with snap cap washers through the windshield and bezel into the well nuts. Once inserted, tighten the screws. Apply pressure to the windshield so the well nuts do not spin while tightening screws.

**STEP 10:** Install the black snap caps.



Photo 4