

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

Qty.	Part Description	Tools required for installation:
1	Windshield	T-25 Torx screw driver
2	M5x30mm Screws	Phillips Screw driver
2	Spacers	
1	Large Well Nut	
1	3/8" Screw	

PowerMadd Cobra windshields install differently than your stock windshield. We mount the shield directly to dash which gives it more stability and strength. Using this method eliminates the need for an outer trim piece.



INSTALLATION INSTRUCTIONS

1. Remove the stock windshield. Some larger shields may have two darts on each side of the hood, gently pull these out first, then pull up on the outer trim of the windshield popping the darts out of the three rubber grommets in the dash.
2. Remove the two dash screws from the dash using a T-25 Torx screw driver (Figure 1). These will be two of the mounting points for your new windshield.
3. Install the large well nut into the hole between the head lights (Figure 1). Some model require removal of grommet. Set windshield onto dash and using the 3/8" bolt lightly tighten the front of the windshield down.
4. While holding the spacer between the windshield and the dash carefully install the M5x30mm Screws. Use care in getting the threads started. Only tighten lightly. Repeat for the opposite side.
5. Verify alignment then tighten all three screws.
6. Save the stock screws and grommets with your stock shield in case you ever want to reinstall it.

