

Install Instructions

PRP Seats

Polaris RZR PRO XP4

Rear Door Bag Installation



Parts

A.



Read through all of the instructions completely before beginning the install.

Parts Included:

A. 2 x PRP Rear Door Bags for RZR PRO XP4 (Driver and Passenger)

Remove all parts from the box and unwrap completely using the packaging to lay out the pieces.

Tools Needed: (not included)

T-40 Torx Socket

Time:

Approx 10 minutes.



1. **Remove the stock bolts from the door (shown in picture).**

Use a T-40 Socket to remove the 11 bolts that connect the door's metal frame to the outside plastic panel.

Once the bolts are removed, take off the plastic panels.



2. **Select the appropriate door bag for the door you are installing on (Driver or Passenger).**

Place the bag in-between the metal frame and the plastic panel.

Push upper and lower storage compartments through the open sections in the frame.



3. **Line up the cut-holes on the bags liner, with the corresponding bolt holes on the frame and plastic panel. Re-install the bolts so that the bag is secured between the door's frame and plastic panel.**

TIP: Start near the door latch, then re-install the bolts one by one (The bolts tend to fall out if you place them in loose all in at once).



4. **Do the same steps for the bag on the other side... and you're all set!**

Thank you! Ride Safe!