



# Universal Light Bar Cradle Bracket Instructions

## Universal Light Bar Cradle Bracket Installation Instructions

Congratulations on your purchase of a high quality PUTCO product.

Contact your PUTCO dealer for other quality accessories.

**Please read all instructions before installation and to check to see that all parts are included.**

KIT CONTENTS:	
Description	Qty.
Universal Cradle Bracket	1
<b>Hardware Kit</b>	
5/16"-18 x 1" Bolt	2
5/16" Washer	2
5/16"-18 Lock Nut	2

### Tools Needed:

- 3/16" Hex Wrench
- 9/16" Wrench
- 3/8" Drill Bit
- Drill

HARDWARE KIT QUANTITIES:	
Description (Cradle Bracket Kit Number)	Qty.
2235, 2240, 2245	1
2250, 2255, 2260, 2265, 2185, 2195, 2225, 2230	2
2270	3

### Universal Cradle Bracket Installation

1. Remove cradle bracket from packaging. Check to see if all parts from above table are included. Also, verify light bar (purchased separately) fits into the universal cradle bracket.
2. Place cradle bracket in desired location (**Verify location is structurally stable for the light bar and bracket**). Mark holes evenly spaced along light bar through the slots. (**The number of holes marked should match the number of bolts in your kit**).
3. Drill 3/8" holes in the locations marked in step 2 and verify there are no obstructions behind hole being drilled.
4. Mount cradle bracket with the hardware provided. Use 3/16" hex wrench and 9/16" wrench to tighten hardware.
5. Mount light bar, refer to Light Bar Installation Instructions.

**For light bar wiring instruction refer to Light Bar Installation  
Instructions**