

Polaris Ranger 2 Piece Roof Installation

Components in this kit:

- 2 Roof sections (L&R)
- 1 Roll of Adhesive Foam Seal
- 11 1/4"-20 x 3/4" Long Bolts
- 11 1/4"-20 Acorn Nuts
- 22 1/4" Flat Washers
- 7 1/4"-28 x 1" Long Bolts
- 7 1/4" x 1" Fender Washers
- 7 Coated P Clamps
- 7 1/4"-28 Nylock Nuts

Tools Required:

- 2 7/16" End Wrenches or Sockets

Please Note:

This is a Universal Hardware Kit.

You may not need all of these components.

First place the Adhesive Foam Seal on the upper overlapping section of roof and trim to length.



Second place the roof sections together and secure one to the other with the 1/4"-20 x 3/4" long bolts through from the top side with a 1/4" flat washer top and bottom and the 1/4"-20 acorn nuts on bottom side of the roof. This works best starting from the middle and working outward.



Place the roof on the vehicle and secure with the six P-clamps using the 1/4"-28 x 1" bolt, 1" Fender washer and 1/4"-28 nut.

