

TERYX/RHINO ROOF

PLEASE NOTE:

- 1. IT IS RECOMMENDED TO REMOVE THIS ROOF BEFORE TRANSPORTING ON ANY OPEN TRAILER OR VEHICLE**
- 2. THE MAXIMUM LOAD CAPACITY OF THE CARGO AREA IS 25 LBS.**
- 3. AT NO TIME SHOULD ANY PERSON SIT OR STAND ON THE ROOF**
- 4. USE CAUTION WHEN CARRYING LOADS! ADDING WEIGHT TO THE TOP OF THE VEHICLE WILL MAKE IT MORE UNSTABLE AND VULNERABLE TO ROLL OVER.**

TOOLS REQUIRED FOR INSTALLATION:

ITEM	DESCRIPTION
1	DRILL
2	1/4" DRILL BIT
3	TAPE MEASURE
4	MARKING UTENSIL
5	TWO 7/16" WRENCHES OR SOCKET WRENCHES

PARTS LIST:

1	5 1 7/8" CLAMP
2	5 1" X 1/4"-28 SS BOLT
3	5 1" FENDER WASHER
4	5 1/4"-28 NYLON INSERT NUTS

INSTALLATION:

- PLACE THE UNIVERSAL ON TOP OF THE ROLL CAGE IN THE DESIRED LOCATION FRONT TO BACK CENTERING THE ROOF SIDE TO SIDE
- FIND THE BEST LOCATION ON YOUR VEHICLE FOR THE CLAMPS THAT WOULD ALLOW A ONE INCH WASHER TO BE PLACED FLAT WHEN TIGHTENED INTO PLACE:

NOTE: PLACING THE CLAMPS AS FAR TO THE OUTSIDE OF THE VEHICLE AS POSSIBLE WILL PROVIDE THE BEST END RESULTS.

- MARK THE LOCATION OF THE MOUNTING HOLES FOR THE CLAMPS AND DRILL 4 HOLES WITH A 1/4" DRILL BIT.
- PLACE A FENDER WASHER ON THE 1/4" BOLT AND FEED IT THROUGH THE ROOF FROM THE TOP DOWN FOR ALL FOUR HOLES
- PLACE THE CLAMPS OVER THE BOLTS THEN A FENDER WASHER AND SECURE WITH THE 1/4" NYLON INSERT NUT.