



***motoalliance***

# **MOTOALLIANCE WINCH MOUNT**

## **MA11915**

### **Honda Big Red**

Thank you for purchasing our MotoAlliance winch mount(s). You now own a premium custom winch mount to allow you to use your winch with your UTV / SxS. Please note the following instructions and heed all warnings.

- Please use common sense when operating your UTV / SxS.
- Read your Winch Operator's Manual and all other Operator Manual's, including warning labels, before operating your UTV / SxS.
- Be observant of moving parts causing entanglement, use extreme caution!

**SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.**

---

**WINCH INSTALLATION:**

1. Your mount requires no additional installation hardware.
2. Remove the front bumper and reserve the hardware.
3. Place the mount plate onto the frame as shown in Figure 1 & tighten bolts.



**Figure 1**

---

## **WIRING INSTRUCTIONS:**

Determine where to install the contactor (solenoid control relay). There is no right or wrong place. We recommend a dry place away from sharp or moving suspension parts. It can be hard to find a totally dry place on an ATV but just try to find the best spot. You may mount it in the front, back or under the seat. You may mount it with U-bolts (holes on contactor are metric.) or bolts. We usually install the contactor in the rear storage compartment if possible because it is dry there. When installing the contactor in the storage compartment, you should attach all the wires first, before bolting it down.

**CAUTION:** It is easier to reverse the polarity of the wires than you think, causing a voltage system short. Please make sure you read the wiring diagrams in your winch manual or refer to our technician's website above. The connections are color coded; from there you will need to determine the best location for mounting the contactor and running the wires on your machine. Zip ties and electrical tape can be quite helpful in the process.

