

Installation Guide for Wes Touring Outlander Max 2013.



We recommend a 1/2" spade bit.

