

ATV Heated Grip Kit with High/Low Switch (215049)

The installation instructions are incorrect. It shows the top pin is for the low circuit and the bottom pin is for the high circuit.

The drawing is correct. Both switches are transposed, so the top pin is connected for the low setting and the bottom pin is connected for the high setting.

My ATV heated grip kit came with two left side grips.

There is not a specific left and right side grip in the ATV heated grip kits. The two grips provided are the same. They can be installed on either side of the handlebar with wire exit facing towards the front of the ATV.

Which wire is ground for the heated grips?

The red wire for each heated grip is ground, the blue wire is low, and the white wire is high.

The heated grips no longer turn on and heat up.

If both heated grips are no longer heating up, this is most likely a switch issue. With a multimeter, check the connectivity between the middle and top pins on low and between the middle and bottom pins on high. If there is no connectivity, the switch needs to be replaced.

Rely on premium powersports handlebars & controls by Heat Demon if you're looking for quality and efficiency.