


Winch Mount


PART # 100935 Hardware Kit: HK-049, HK-031




## **INSTALLATION INSTRUCTIONS:**

- Take off the front panel by removing 2 Bolts (A) and two screws (B) as shown in Figure 2.
- 2. Install Roller Fairlead to mount plate using hardware provided with the winch. See Figure 3.
- 3. Install Winch to mount plate using the hardware provided with the winch. See Figure 3.
- 4. Place winch and mount plate assembly onto machine as shown in Figure 4.


*Note: For some winches you may need to rotate your leads.* 



"Figure 4" Winch and Mount Assembly Install



"Figure 2" Front Panel Removal




"Figure 3" Winch Install and Fairlead


- 5. Install mount plate to machine using the 4 Bolts (C) provided with the winch mount. See Figure 5.
- 6. Reinstall front panel.
- 7. Use the instructions provided with your winch, wire accordingly.



"Figure 6" Fully Installed



"Figure 5" Winch Mount Bolt Install



## **Optional Switch Mount Instructions\***

"Figure 6" Mini-Rocker Mounting

## WIRING INFORMATION

- 1. Find a dry location for the contactor. There is no specific location on this machine.
- 2. Mini-Rocker Switch Hardware kit. This allows you to mount your usual handle bar mounted switch to almost any desired location.
  - a. Remove handlebar mount hardware from the switch.
  - b. Locate desired mounting location
  - c. Mark and drill two switch holes through dash using switch housing as a template
  - d. Drill a 3rd hole for the switch wiring.
  - e. Assemble per Figure 6.
- 3. Find a location that suits your purposes for the mini-rocker switch and hand remote.



