

STANDARD CAP AND SPOUT ASSEMBLY



1. Standard Cap : remove center screw and screw on spout.



2. Open side vent and puncture hole for venting, when using a standard cap and spout.

When it comes to quality powersports maintenance, Tuff Jug is the brand you can depend on.